

CLOCK RADIO



MODEL: 329796
LARGE LED CLOCK RADIO

USER MANUAL



Goodmans

1 Welcome

2 Your Clock Radio

- 2.1 In The Box
 - 2.2 Front View
 - 2.3 Rear View
-

3 Quick Setup

- 3.1 Getting Your Clock Radio Ready For Use
-

4 Features

Getting Your Clock Radio Ready For Use

- 4.1 Setting The Time And Date
 - 4.2 Setting The Alarm
 - 4.3 Turning The Alarm On/Off
 - 4.4 To Set The Alarm To Buzzer
 - 4.5 Set The Alarm To Last Radio Station Played
 - 4.6 Using The Snooze Function
 - 4.7 Turning The Alarm Off Each Day
 - 4.8 Using The Dimmer Function
 - 4.9 Turning The Radio On / Off And Selecting The Band
 - 5.0 Searching For Radio Stations
 - 5.1 Using The Radio Station Preset Memory
 - 5.2 Using The Sleep Function
-

6 Troubleshooting

7 Technical Specifications

8 Customer Support

1 Welcome

Thank you for choosing this Goodmans product. We've been making electronics for the British people for 70 years. Each of our projects has been carefully designed to be great at what it does and this one is no exception. We hope you enjoy your new Alarm Clock Radio.

2 Your Radio

2.1 In The Box

Carefully remove your Clock Radio from the box.

Inside the box you will find:

- Clock Radio
- AC Adapter
- Quick Start Guide
- Guarantee Booklet

If any of these items are missing contact Customer Support at goodmans@bmstores.co.uk



Power

Your Clock Radio requires a mains supply of 230V AC ~ 50 Hz. or 1 X CR2025 battery (not supplied). Please ensure that your mains supply is compatible before use. Disconnect the Power Cord from the mains or remove the batteries when not in use.

Position of Clock Radio

Place on a flat, stable surface that is not subject to vibrations.

Avoid the following locations:


- Where it is exposed to direct sunlight
- Where it is close to heat radiating sources
- Where the humidity is high and ventilation is poor
- Where it is dusty

Adjusting the Aerial

Fully unravel the aerial to ensure good reception for the Clock Radio. It may be necessary to alter the position of the Clock Radio and/or the aerial to achieve the best signal.


2.2 Front View

- A** M BUTTON
- B** LEFT BUTTON
- C** RIGHT BUTTON
- D** SNOOZE/SLEEP
- E** - BUTTON
- F** + BUTTON
- G** POWER
- H** LED Display
- I** Sleep Indicator
- J** Alarm 1 Indicator
- K** Alarm 2 Indicator



2.3 Rear View


- L** Aerial
- M** Speaker
- N** Stand
- O** Battery compartment
Takes 1 x 'CR2025' battery
- P** AC Power
Used to connect the Radio to the mains power supply.



3 Quick Setup

3.1 Getting Your Clock Radio Ready For Use

1. Unravel the Aerial.
2. Remove the battery compartment cover.
3. Place a CR2025 battery into the compartment, taking care of polarity.
4. Connect the power cord into the AC-In socket
5. Connect the Power Plug to the mains socket.
6. Press the power on button.



4 Features

SETTING UP YOUR CLOCK RADIO

4.1 Setting The Time And Date

1. Press and hold the M button for a few seconds. The 'hour' digit(s) on the led display will begin to blink. Press either the ⏪ or the ⏩ button to adjust the 'hour' digit(s). Once the correct 'hour' is displayed press the M button to confirm.
2. The 'minute' digits will now be to blink. Press either the ⏪ or the ⏩ button to adjust the 'minute' digits. Once the correct 'hour' and 'minutes' are displayed press the M button to confirm.
3. Now press either the ⏪ or the ⏩ button to select 12 or 24 hour time (shown on the screen as '12h' or '24h'). Once you have made your selection press the M button to confirm.
4. The 'year' will then begin flashing, press either the ⏪ or the ⏩ button to adjust the year. Once the correct year is displayed, press the M button to confirm.
5. The 2 numbers that are now flashing represent the current 'month'. You can press either the ⏪ or the ⏩ button to adjust the 'month' and then press the M button to confirm.
6. The letter 'd' followed by 2 numbers will flash on the led display. This represents the 'day' of the month. You can press either the ⏪ or the ⏩ button to adjust the 'day' and then press the M button to confirm.
7. The led display will now show the correct time and all of the changes you have made to the time and date will be saved.



4.2 Setting The Alarm

1. Press and hold the 'Power' button for a few seconds, and begin by setting Alarm 1. The current time for Alarm 1 will appear on the display with the 'Hour' digit(s) flashing along with the Alarm 1 LED indicator.
2. Press either the ⏪ or the ⏩ button to adjust the 'Hour' digit(s). After the desired 'Hour' is displayed, press the Power button to confirm.
3. The 'Minute' digits will blink. Press either the ⏪ or the ⏩ button to adjust the 'Minute' digits. Once the correct 'Hour' and 'Minutes' are displayed press the Power Button to confirm.
4. Next, select the days you want to set the alarm for. Press either the ⏪ or the ⏩ button to select one of the options (on the next page) to choose the days the alarm will be activated. Once you have selected your desired setting, press the Power button TO CONFIRM.
5. Repeat steps 2-4 to set Alarm 2 and the Alarm 2 LED indicator will flash. Enter the desired time for Alarm 2. Once this is completed your settings for Alarms 1 and 2 will be saved.



- 1-7: Set on Every day of the week
- 6-7: Set on Saturday & Sunday
- 1-5: Set on Monday to Friday
- 1: Set on Monday only
- 2: Set on Tuesday only
- 3: Set on Wednesday only
- 4: Set on Thursday only
- 5: Set on Friday only
- 6: Set on Saturday only
- 7: Set on Sunday only

4.3 Turning The Alarm On/Off

To turn the alarm on (after both alarms have been set), determine which alarm you want to activate (alarm 1 or alarm 2) and ensure that the alarm clock radio is in normal mode (i.e. The radio is not on). Note: when the radio is on, the alarm 1 and alarm 2 buttons will function as volume increase/decrease buttons.

1. The alarm can be set to sound as a buzzer or as the last radio station played. If you set the alarm to buzzer, the alarm will sound as a series of beeps when it is activated. If it is set to the last radio station played, when the alarm sounds, it will simply turn on the radio to the last radio station played.

4.4 To Set The Alarm To Buzzer

1. The '-' button is the Alarm 1 button. To activate Alarm 1, press the '-' button repeatedly until 'bb' is displayed on screen. Wait a few seconds until the clock reverts back to the current time and you will notice that the Alarm 1 LED indicator is illuminated, this indicates that Alarm 1 is on.
2. The '+' button is the Alarm 2 button. To activate Alarm 2, press the '+' button repeatedly until 'bb' is displayed on screen. Wait a few seconds until the clock reverts back to the current time and you will notice that the Alarm 2 LED indicator is illuminated, this indicates that Alarm 2 is on.



4.5 Set The Alarm To Last Radio Station Played

1. The '-' button is the Alarm 1 button. To activate Alarm 1, press the '-' button repeatedly until the frequency of the last radio station played is displayed on screen. Wait a few seconds until the clock reverts back to the current time and you will notice that the Alarm 1 LED indicator is illuminated, this indicates that Alarm 1 is on.
2. The '+' button is the Alarm 2 button. To activate Alarm 2, press the '+' button repeatedly until the frequency of the last radio station played is displayed on screen. Wait a few seconds until the clock reverts back to the current time and you will notice that the Alarm 2 LED indicator is illuminated, this indicates that Alarm 2 is on.
3. Choose which alarm you want to turn OFF (Alarm 1 or Alarm 2) and ensure that the Alarm is in normal mode (i.e. the radio is NOT on). Press either the '-' button (for Alarm 1) or the '+' button (for Alarm 2) repeatedly until 'OFF' is displayed on screen. Wait a few seconds until the clock reverts back to the current time. You will notice that the relevant Alarm LED indicator will no longer be illuminated which indicates that the relevant Alarm is OFF.

4.6 Using The Snooze Function

- The Alarm Clock Radio has a snooze function, which stops the alarm from sounding for 9 minutes. This feature allows you to ‘snooze’ and wake up more naturally.
- When the alarm sounds, simply press the SNOOZE/SLEEP button on the top of the Alarm Clock (No.4 on the diagram on the “Description of Parts” diagram). The alarm will then cease and restart in approximately 9 minutes.



4.7 Turning The Alarm Off Each Day

- To turn the Alarm OFF each day, simply press the Power button. The alarm will stop sounding and will not sound again until the next set day (i.e. if your alarm is only set for every Monday, the alarm will not sound until the following Monday).

4.8 Using The Dimmer Function

- The Alarm Clock Radio has a Dimmer function which allows you reduce or increase the brightness of the LED display. When the Alarm Clock Radio is in normal mode, (i.e. the alarm is not sounding), simply press the SNOOZE/SLEEP button to dim or increase the brightness.



4.9 Turning The Radio On / Off And Selecting The Band

1. To turn the radio ON, simply press the Power button once, this will activate the FM radio.
2. If you wish to select the AM band press the Power button once again. Pressing the Power button will toggle between AM and FM radio.
3. To turn the radio OFF, simply press and hold down the Power button for a few seconds until the radio ceases.
4. You can increase or decrease the Volume of the speaker, while the radio is turned ON. Simply press the '-' button to decrease, or press the '+' button. You can press the button repeatedly or hold the button down until you reach your desired volume level.



5.0 Searching For Radio Stations

1. To search for radio stations, firstly ensure that the radio function is turned ON and is set to your desired band (AM or FM).
2. You can perform an auto search where the tuner will automatically search up or down the frequency range and stop on the first available station. To do this press and hold either **⏪** or the **⏩** buttons until you notice the frequencies display on screen start to change. After the tuner stops on the first available station, you can repeat the process until you reach your desired station.
3. Pressing the **⏪** button will perform an auto search down the frequency range. Pressing the **⏩** button will perform an auto search up the frequency range.
4. You can perform a manual search to find your desired radio station. To do this, simply repeatedly press (do not hold) either the **⏪** or the **⏩** buttons to search up or down the frequency range until you reach the desired frequency/radio station.



5.1 Using The Radio Station Preset Memory

The Alarm Clock Radio has a 20 station memory for the FM and AM tuners. You can save your favourite stations into the alarm's memory so you can quickly tune to these stations. These pre-sets can be overwritten at any time.

1. Tune the radio to your desired station. (Refer to “turning the radio on/off and selecting the band” section).
2. Press and hold the M button until ‘p01’ begins to flash on screen.
3. Press either the **⏪** or the **⏩** buttons to select the preset you would like to save this to (from 1 – 20). Once you have reached your desired preset, press the M button once to save.
4. You can overwrite any preset at any time by following the previous procedure and ensuring you select the correct preset to overwrite with a new station.
5. If you would like switch to one of your saved radio stations, simply press the M button until ‘p01’ is displayed (assuming that you are listening to the station saved in the first preset). Press either the **⏪** or the **⏩** buttons to move up or down your preset list. The saved stations will automatically play as soon as they are selected. After a few seconds, the alarm clock radio will display the time on screen once again.



5.2 Using The Sleep Function

1. When listening to the radio, press and hold the SNOOZE/ SLEEP button until '120' is displayed on screen.
2. '120' represents the number of minutes you would like the radio to continue playing before it turns itself off. To adjust the length of time, press the snooze button repeatedly until you reach the desired minute setting.
3. The time will appear on the display a few seconds after you have reached your desired setting. The sleep LED indicator on the left side of the screen will illuminate and the clock's radio will automatically turn off according to your selected time.
4. To cancel, press and hold the SNOOZE/SLEEP button until you reach the minute select screen which will show your preselected minutes. Press the SNOOZE/SLEEP button again, repeatedly, until the time is displayed on screen. The SLEEP time will be cancelled and the SLEEP LED indicator will no longer be illuminate.



6 Troubleshooting

Problem	What to do
The Alarm Clock Radio is not turning on.	Check that the power adaptor is correctly connected at both ends.
There is no sound whilst in Radio Function.	Check that the volume has been correctly adjusted. Check that the Clock is correctly set to Radio Mode. Check other radio stations.
Crackling whilst in radio mode.	Generally caused by a weak signal. Try adjusting the position of the antenna cable. Try a different radio station with better reception.
Alarm does not function.	Ensure that the Alarm time and frequency has been set correctly. Ensure that the Alarm has been correctly activated. Increase the radio volume. Ensure the radio has been tuned correctly to a station.
The Alarm Clock Radio did not save original time during a power outage.	Change the back-up battery.

7 Technical Specification

Model Number	329796
Power Supply	220-240V AC ~ 50 Hz Adapter: AC 6V, 400mA  1 X CR2025 battery not supplied
Frequency Range	FM: 87.5-108MHz

8 Customer Support

For all product support, please email:
goodmans@bmstores.co.uk

This product is intended for use within the UK

Declaration of Conformance

The full text of the EU declaration of conformance is available at the following internet address:

<http://www.bmstores.co.uk/technical-information>

